


# Hoop Chart Sign

Hoop Chart	
Millimeters	Inches
100 x 100	3.94 x 3.94
120 x 120	4.72 x 4.72
130 x 180	5.12 x 7.09
150 x 240	5.91 x 9.45
200 x 260	7.87 x 10.24
200 x 360	7.87 x 14.17



**Hoop:** 130mm x 180mm

**Stitches:** 20,660

**Colors:** 16

**Width:** 127.0mm

**Length:** 167.2mm

## *Items needed:*

### **Fabric:**

2 Pieces **6 x 7½** inches - Front & Back of Sign

### **Quilt Batting:**

1 Piece **5½ x 7** inches

**Wash-away Stabilizer:** Large enough to hoop in the 130mm x 180mm hoop


**Cord or Ribbon:** **12 to 15 inches**

**Tape or Glue:** Used for holding Fabric and Ribbon or Cord in place.


### **Embroidery Thread:**

The thread colors depend on the color of fabric you use. You do not have to change the thread **16** times. Color changes are to prompt your sewing machine to stop after each step.

## *Hoop the Stabilizer*



1  Sew the placement stitch. Lay the **5½ x 7** inch piece of Batting over the stitching.




2



the Front 6 x 7½ inch piece of Fabric over the Batting.


Stitch and **Trim**. Lay



3



Sew. **Do Not Trim**.



4



Sew the Crosshatch stitch.



5



Sew "Hoop Chart".



6 

Sew the Millimeters and Inches.




Sew




7 


Sew the Chart Numbers.



8   
 9   
 10   
 11 




Sew the thread spools in your choice of colors. Remove the hoop. Turn over. Lay the Back 6 x 7½ piece of fabric face up over the back. Tape the four corners and anywhere else needed. Replace the hoop.



12 

Sew to attach the back piece.



13



Sew the Decorative border stitch.



Remove the hoop. Trim the front and back close to the stitching. Replace the hoop.

Remove the hoop. Trim the front and back close to the stitching. Replace the hoop.



Measure in  $\frac{1}{4}$  to  $\frac{1}{2}$  inch from the side seam at the top and mark. Lay the ribbon or cord with the ends facing toward the top. Glue or tape to hold.

Measure in  $\frac{1}{4}$  to  $\frac{1}{2}$  inch from the side seam at the top and mark. Lay the ribbon or cord with the ends facing toward the top. Glue or tape to hold.



14



Sew.

**Trim** the ends, flip up, and glue or tape.



Remove the design from the hoop. **Trim** the stabilizer close to the stitches. Wet your finger and rub along the edges to remove the excess Wash-away stabilizer.

**If you make it too wet, the stabilizer will cause the fabric to pucker. If that happens you will have to soak or wash it to remove it all.**

